



Sensors Introduction to polarimetric imaging

Christophe Stolz



Master VIBOT

2012

1

Summary

- I. Introduction
- II. Polarization of light
 - polarisation states and parameters
- III. Stokes Model
- IV. O. Morel :
 - Polarimetric imaging
 - example and applications

2

I Introduction


- Non Conventional optical Imaging:
Imaging techniques such as
microscopy
radar imaging
polarimetric imaging
holography
- Applications:
ground data,
metrology,
health



3

I Introduction

- Recall of EM spectrum




4

I Introduction

- Radar imaging : examples of images

C-band false colour composite and single channel intensity images from SIR-C for an ice infested region of the Labrador Sea off the coast of Newfoundland.




"Remote Sensing Glossary" of the Canada Centre for Remote Sensing

5


I Introduction

- Remote sensing : active imaging middle Infrared

Truck with sand color on a the sand



Passive




Active

6


II 1. Polarization of light

- monochromatic plane wave vectors $\vec{E}, \vec{B}, \vec{k}_0$ forming a direct trihedral



$$\vec{E} = \vec{E}_0 e^{i(\omega t - \vec{k}_0 \cdot \vec{r})}$$

$$\|\vec{k}_0\| = k_0 = \frac{2\pi}{\lambda}$$



7

II Polarization of light

- Wave parameters

- Intensity $\Rightarrow i = |a|^2 \Rightarrow$




- Frequency $c_n = \frac{1}{n} \cdot (\lambda_0 v); e_{ph} = h\nu$




- Phase

$$\varphi = 2\pi \frac{r}{\lambda_n}$$




Images: D. Vukicevic

- Polarization



II Polarization of light

- How to realize a plane wave ?
- Laser beam expander



- Example at 633 nm, pinhole size of 15 μm

$$D_{\text{pinhole}} = \frac{F\lambda}{a}$$

9

II Polarization of light : Polarization states

- Polarization states
in the preceding coordinate system

$$\vec{E} = \vec{E}_1 + \vec{E}_2 = E_1 \vec{e}_x + E_2 \vec{e}_y \quad \text{where} \quad \begin{cases} E_x = E_{0x} \cos(\omega t - \vec{k}_0 \cdot \vec{r} - \varphi_1) \\ E_y = E_{0y} \cos(\omega t - \vec{k}_0 \cdot \vec{r} - \varphi_2) \end{cases}$$

$\delta = \varphi_2 - \varphi_1$ The phase delay between E_1 and E_2

When: $\frac{d\delta}{dt} = 0$ The wave is polarized \Rightarrow three polarization states

Linear polarization $\delta = m\pi$ with $m \in \mathbb{Z}$


Circular polarisation $\begin{cases} a_1 = a_2 \\ \delta = (2m+1)\frac{\pi}{2} \text{ avec } m \in \mathbb{Z} \end{cases}$

Elliptical polarization

10


II Polarization of light : Polarization states

- 3D representations



II Polarization of light : Polarization states

- Polarization states: polarization plane



II Polarization of light : Polarization states

- Other representation:

with E_0^2 the light intensity and

$$\begin{cases} E_x = E_0 \cos \varphi \cos(\omega t - \vec{k}_0 \cdot \vec{r} - \varphi_1) \\ E_y = E_0 \sin \varphi \cos(\omega t - \vec{k}_0 \cdot \vec{r} - \varphi_2) \end{cases}$$

$$\tan \varphi = \frac{a_2}{a_1} = \frac{E_{0y}}{E_{0x}}$$


Ellipse equation

$$\left(\frac{E_x}{E_{0x}} \right)^2 + \left(\frac{E_y}{E_{0y}} \right)^2 - 2 \frac{E_x}{E_{0x}} \frac{E_y}{E_{0y}} \cos \delta = \sin^2 \delta$$

ψ azimuth $\in [0, \pi]$; $\tan 2\psi = \tan(2\varphi) \cos \delta$

χ ellipticity $\in \left[-\frac{\pi}{4}, \frac{\pi}{4} \right]$; $\sin 2\chi = -\sin 2\varphi \sin \delta$

φ diagonal angle



13

II Polarization of light : Polarization states

- Ellipse equation in the X and Y basis

- Canonical form of the ellipse $\frac{E_x^2}{a^2} + \frac{E_y^2}{b^2} = 1$

- Component of the electrical field:

$$\begin{aligned} E_x &= E_0 \cos \psi + E_0 \sin \psi \\ E_y &= -E_0 \sin \psi + E_0 \cos \psi \end{aligned} \quad I = E_{0x}^2 + E_{0y}^2 = a^2 + b^2$$

- Development and identification :

$$\sin^2 \phi \left(\frac{\cos^2 \psi}{a^2} + \frac{\sin^2 \psi}{b^2} \right) = \frac{1}{A_1^2} \quad (1)$$


$$\sin^2 \phi \left(\frac{\sin^2 \psi}{a^2} + \frac{\cos^2 \psi}{b^2} \right) = \frac{1}{A_2^2} \quad (2)$$

$$\sin^2 \phi \cos \psi \sin \psi \left(\frac{1}{a^2} - \frac{1}{b^2} \right) = -\frac{\cos \phi}{A_1 A_2} \quad (3)$$


14

II Polarization of light: producing

- Polarizer filter: schematized as a grid



- Dichroic polarizer : absorb one of the component of the incident light (anisotropic)



- Malus law


$$I = I_0 \cos^2 \alpha$$

Figure 8.13 A dichroic crystal. The E field parallel to the optic axis is transmitted without any diminution. The naturally occurring optics are oriented along the optic axis. The two faces of the tourmaline crystals correspond to the optic axes. (Photo by E.Z.)

15

II Polarization of light: producing

- Malus law



- Intensity after two crossed polarizer ?

16

II Polarization of light: producing


- Pictures seen through polarizer(s)

Reflection attenuation



avec filtre polarisant

Analysis of mechanic tension of plexiglass through crossed polarizers





17

II Polarization of light: producing

- Reflection of a linearly polarized light

1. linearly polarized light ...



2. reflect off sample ...

18

II Polarization of light: producing

- Anisotropic media: retarder plate
- Birefringent media: characterized by 2 orthogonal axis with 2 different index each index introduce a different phase speed
- ΔL : slow or extraordinary axis
- ΔR : fast or ordinary axis

...ns within any given system. The dichroic
the previous section. We have seen
saw there that in the dry case the lattice is
: completely isotropic. In the birefringent case the
the electrons would be anisotropic. We w
e use of the Drude-Lorentz model fo
g the electrica...
Fig. 3.14(b) we rep...
ing the simple mechanical model of a spher

A calcite crystal (blunt corner on the bottom). The transmission axes of the two polarizers are parallel to their short edges. Where the image is doubled the lower, undeflected one is the ordinary image. Take a long look: there's a lot in this one. (Photo by E.H.)


19

F:\SauvegardeIUT\Documents\Enseignement\MasterVIBOT\coursPola\TD_Exam\Numérisé à 08-10-2010 08-28 (2)

II Polarization of light: producing

- Particular plates:
 - quarter wave plate output polarized elliptically, circular if input in an axis direction
 - half wave plate rotate linear polarization

$$\phi = \frac{(n_L - n_R)2\pi e}{\lambda}$$



II Polarization of light: modulating


- Pockels effect : electro-optic effect in some crystals involving polarization modulation
- Ex : LiNbO₃ crystals, birefringence depending of electrical field applied to it
- In that case $n_e - n_o = \alpha E$ with $E = \frac{V}{d}$ so $\phi = \frac{2\pi}{\lambda} \alpha L \frac{V}{d}$
d distance between electrodes
- Particular voltage $V\pi \Rightarrow$ act like a half wave plate
- Applications: fast optical shutter (0, 90°), amplitude modulation




21

II Polarization of light: modulating

● Liquid crystals retarders



Liquid Crystal Variable Retarder
construction showing molecular alignment
(a) without and (b) with applied voltage
(drawing not to scale)



Retardance curve
(with no compensator)

from Meadowlark

22

II Polarization of light: modulating


- Liquid Crystal retarder: retardance and Outout wave from voltage

Voltage (volts)	Retardance	Output
$V \sim 2$	$\delta = \lambda/2$	↑↓
$2 < V < 4$	$\lambda/4 < \delta < \lambda/2$	○
$V \sim 4$	$\delta = \lambda/4$	○
$4 < V < 7$	$0 < \delta < \lambda/4$	○○
$V \sim 7$	$\delta = 0$	↔↔

23

II Polarization of light: modulating


- Creating / modulating polarization:
- Polarizer + quarter wave plate: elliptic or circular polarization
- Polarization attenuator:



24

II Polarization of light: modulating


- Polarization rotation
- Half wave plate
- Or with liquid crystal cell



25

II Polarization of light: modulating

- How to determine the polarization of an unknown wave ?



26

III Stokes Model

- Stokes vector

$$S = \begin{pmatrix} S_0 \\ S_1 \\ S_2 \\ S_3 \end{pmatrix} = \begin{pmatrix} I \\ Q \\ U \\ V \end{pmatrix} = \begin{pmatrix} \langle E_x^* E_x \rangle + \langle E_y^* E_y \rangle \\ \langle E_x^* E_x \rangle - \langle E_y^* E_y \rangle \\ \langle E_x E_y^* \rangle + \langle E_x^* E_y \rangle \\ i[\langle E_x E_y^* \rangle - \langle E_x^* E_y \rangle] \end{pmatrix} = \begin{pmatrix} I_0 + I_{90} \\ I_0 - I_{90} \\ I_{45} - I_{-45} \\ I_d - I_g \end{pmatrix} \quad \text{For measurement purpose}$$

- Where :

S_0 : intensity of light

S_1, S_2 : difference between intensities respectively at 0° and 90° and at 45° and -45°

S_3 : difference between right (d) and left (g) circular components

- Properties : for partial polarization $S_0 \geq \sqrt{S_1^2 + S_2^2 + S_3^2}$ 27

III Stokes Model

- Examples of stokes vectors (normalized)

$$\begin{pmatrix} 1 \\ 0 \\ 0 \\ 0 \end{pmatrix} \text{ Unpolarized} \quad \begin{pmatrix} 1 \\ -1 \\ 0 \\ 0 \end{pmatrix} \text{ Linearly polarized (vertical)} \quad \begin{pmatrix} 1 \\ 1 \\ 0 \\ 0 \end{pmatrix} \text{ Linearly polarized (horizontal)}$$

$$\begin{pmatrix} 1 \\ 0 \\ 1 \\ 0 \end{pmatrix} \text{ Linearly polarized (+45°)} \quad \begin{pmatrix} 1 \\ 0 \\ -1 \\ 0 \end{pmatrix} \text{ Linearly polarized (-45°)}$$

$$\begin{pmatrix} 1 \\ 0 \\ 0 \\ 1 \end{pmatrix} \text{ Right-hand circularly polarized} \quad \begin{pmatrix} 1 \\ 0 \\ 0 \\ -1 \end{pmatrix} \text{ Left-hand circularly polarized}$$

III Stokes Model

- Link with the polarization ellipse:

$$S = \begin{pmatrix} S_0 \\ S_1 \\ S_2 \\ S_3 \end{pmatrix} = \begin{pmatrix} E_{0x}^2 + E_{0y}^2 \\ E_{0x}^2 - E_{0y}^2 \\ 2E_{0x}E_{0y} \cos \delta \\ 2E_{0x}E_{0y} \sin \delta \end{pmatrix} = \begin{pmatrix} I \\ I_{pol} \cos 2\chi \cos 2\psi \\ I_{pol} \cos 2\chi \sin 2\psi \\ I_{pol} \sin 2\psi \end{pmatrix}$$

Phase angle

$$\delta = \arctan \left(\frac{S_3}{S_2} \right)$$

ellipticity


Diagonal angle

$$\varphi = \frac{1}{2} \arccos \left(\frac{S_1}{\sqrt{S_1^2 + S_2^2 + S_3^2}} \right)$$

azimuth

$$\psi = \frac{1}{2} \tan^{-1} \left(\frac{S_2}{S_1} \right)$$


$$\chi = \frac{1}{2} \arcsin \left(\frac{S_3}{\sqrt{S_1^2 + S_2^2 + S_3^2}} \right)$$



29

III Stokes Model

- Poincaré sphere
- Representation of polarization states:
center is unpolarized light
surface is polarized light
equator plane represents linear waves
poles represent circular waves
north hemisphere is right elliptically polarized light
- Orthogonal polarization states are diametrically opposite



From R.A Chipman

30

III Stokes Model

- degree of polarization DOP

$$DOP = \frac{\sqrt{s_1^2 + s_2^2 + s_3^2}}{s_0} = \frac{I_{pol}}{I} \leq 1 \quad \text{or} \quad \frac{I_{\parallel} - I_{\perp}}{I_{\parallel} + I_{\perp}}$$

- degree of linear polarization DOLP

$$DOLP = \frac{\sqrt{s_1^2 + s_2^2}}{s_0}$$

- Degree of circular polarization


$$DOCP = \frac{s_3}{s_0}$$

31


III Stokes Model

- Example of mapping

Stokes images



Representation on the sphere
Here 12% of the pixels are to be rejected




From J. Zallat

32

III Stokes Model


- Representation of Stokes vector in Color HSV coordinates

$$H = \tan^{-1} \left(\frac{\bar{S}_2}{\bar{S}_1} \right) \quad S = \sqrt{\bar{S}_1^2 + \bar{S}_2^2} \quad V = \frac{1}{2} - \frac{\bar{S}_3}{2}$$




- Example with medical images

Stokes








HSV



J. Zallat, C. Collet, A. De Martino and S. Ainouz, "Interpretation physique d'images codées en polarisation par prévisualisation couleurs", Journées Imagerie non conventionnelles, CNRS, 2006. 33

III Stokes Model

- Noise recovery



Sfikas JOSA A 2011 34

III Stokes Model

- Mueller matrix :
represent the action of an optical system on an incident wave represented by its stokes vector

$$\vec{S}_o = [\mathbf{M}] \cdot \vec{S}_i$$

$$[\mathbf{M}] = \begin{bmatrix} M_{00} & M_{01} & M_{02} & M_{03} \\ M_{10} & M_{11} & M_{12} & M_{13} \\ M_{20} & M_{21} & M_{22} & M_{23} \\ M_{30} & M_{31} & M_{32} & M_{33} \end{bmatrix} = M_{00} \begin{pmatrix} 1 & \vec{D}^T \\ \vec{P} & \mathbf{m} \end{pmatrix}$$

35

III Stokes Model

- Examples of Mueller matrices

Polarizer (perfect) oriented with angle α (rotator):

$$M_{pol} = \frac{1}{2} \begin{bmatrix} 1 & \cos 2\alpha & \sin 2\alpha & 0 \\ \cos 2\alpha & \cos^2 2\alpha & \cos 2\alpha \sin 2\alpha & 0 \\ \sin 2\alpha & \cos 2\alpha \sin 2\alpha & \sin^2 2\alpha & 0 \\ 0 & 0 & 0 & 0 \end{bmatrix}$$

Retarder with a delay δ oriented with angle α :

$$M_{ret} = \begin{bmatrix} 1 & 0 & 0 & 0 \\ 0 & c^2 + s^2 \cos \delta & sc(1 - \cos \delta) & -s \sin \delta \\ 0 & sc(1 - \cos \delta) & s^2 + c^2 \cos \delta & c \sin \delta \\ 0 & s \sin \delta & -c \sin \delta & \cos \delta \end{bmatrix} \quad c = \cos 2\alpha, s = \sin 2\alpha$$

Depolarizer

$$\begin{bmatrix} 1 & 0 & 0 & 0 \\ 0 & a & 0 & 0 \\ 0 & 0 & b & 0 \\ 0 & 0 & 0 & c \end{bmatrix} \quad |a|, |b|, |c| \leq 1$$

36

III Stokes Model

- Mueller matrix :
- Polarisance : DOP of the emerging light when incident light is unpolarized

$$\vec{P}^T = \frac{1}{m_{00}} (m_{10} \ m_{20} \ m_{30}) \quad P = \frac{1}{m_{00}} \sqrt{m_{10}^2 + m_{20}^2 + m_{30}^2} \leq 1$$

- Diattenuation: DOP of the emerging light when incident light is polarized

$$\vec{D}^T = \frac{1}{m_{00}} (m_{01} \ m_{02} \ m_{03}) \quad D = \frac{T_{\max} - T_{\min}}{T_{\max} + T_{\min}} = \frac{1}{m_{00}} \sqrt{m_{01}^2 + m_{02}^2 + m_{03}^2} \leq 1$$

37

III Stokes Model

- Link with Jones vector : From coherence matrix terms

$$S = A\Gamma \text{ with } \Gamma = \begin{bmatrix} \langle E_x E_x^* \rangle \\ \langle E_y E_y^* \rangle \\ \langle E_x E_y^* \rangle \\ \langle E_y E_x^* \rangle \end{bmatrix} \quad A = \begin{bmatrix} 1 & 1 & 0 & 0 \\ 1 & -1 & 0 & 0 \\ 0 & 0 & 1 & -i \\ 0 & 0 & -1 & i \end{bmatrix}$$

- From $S' = MS$ we can derive the Mueller matrix:

$$M = A(J \otimes J^*) A^{-1}$$

- Define H as the physical admissibility of matrix M


$$H = \frac{1}{4} \sum_{k,l=0}^3 m_{kl} D_{kl}$$

M is physically valid if the eigenvalues of H are real positive

38

III Stokes Model


- Other decomposition: $\mathbf{M} = \mathbf{M}_{\text{dep}} \mathbf{M}_{\text{ret}} \mathbf{M}_{\text{diatt}}$
- Images of bones cuts



B. Laude-Boulesteix, A. De Martino, B. Dréville, and L. Schwartz, "Mueller Polarimetric Imaging System with Liquid Crystals," Appl. Opt. 43, 2824-2832 (2004). 39

III Stokes Model

- Stokes vector measurement: classical configuration
- Polarizer and Retarder




- Intensity at the output:

$$I(\alpha, \delta) = \frac{1}{2} [S_0 + S_1 \cos 2\alpha + S_2 \sin 2\alpha \cos \delta + S_3 \sin 2\alpha \sin \delta]$$

III Stokes Model

- Stokes/Mueller polarimeter :



41

III Stokes Model

- Stokes measurement: with a rotating quarter wave plate: $\delta = 90^\circ$

$$S_0 = I(0^\circ, 0^\circ) + I(90^\circ, 0^\circ)$$

$$S_1 = I(0^\circ, 0^\circ) - I(90^\circ, 0^\circ)$$

$$S_2 = 2I(45^\circ, 0^\circ) - S_0$$

$$S_3 = 2I(45^\circ, 90^\circ) - S_0$$

- Take care of absorption loss in components p separately measured electric field

$$E'_x = E_x e^{i\phi/2} p_x \text{ with } p_x = e^{-\alpha_x}$$

$$E'_y = E_y e^{i\phi/2} p_y \text{ with } p_y = e^{-\alpha_y}$$

- Mueller matrix for anisotropic absorbing retarder

$$M = \frac{1}{2} \begin{pmatrix} p_x^2 + p_y^2 & p_x^2 - p_y^2 & 0 & 0 \\ p_x^2 - p_y^2 & p_x^2 + p_y^2 & 0 & 0 \\ 0 & 0 & 2p_x p_y \cos\phi & 2p_x p_y \sin\phi \\ 0 & 0 & -2p_x p_y \sin\phi & 2p_x p_y \cos\phi \end{pmatrix}$$

42

III Stokes Model

- Anisotropic retarder: behave like a polarizer and a retarder
- Then for a polarizer at angle γ

$$M = \frac{p}{2} \begin{pmatrix} 1 & \cos 2\gamma & 0 & 0 \\ \cos 2\gamma & 1 & 0 & 0 \\ 0 & 0 & \sin 2\gamma \cos \phi & \sin 2\gamma \sin \phi \\ 0 & 0 & -\sin 2\gamma \sin \phi & \sin 2\gamma \cos \phi \end{pmatrix} \quad p^2 = p_x^2 + p_y^2$$

- Intensity at the output

$$I(\phi, \theta) = \frac{p^2}{2} [(1 + \cos 2\theta \cos 2\gamma) S_0 + (\cos 2\gamma + \cos 2\theta) S_1 + (\sin 2\gamma \cos \phi \sin 2\theta) S_2 + (\sin 2\gamma \sin \phi \sin 2\theta) S_3]$$

- So:

$$\begin{aligned} S_0 &= \frac{1}{p^2} [I(0^\circ, 0^\circ) + I(90^\circ, 0^\circ)] \\ S_1 &= \frac{1}{p^2} [I(0^\circ, 0^\circ) - I(90^\circ, 0^\circ)] \\ S_2 &= \frac{1}{p^2} I(45^\circ, 0^\circ) - S_0 \\ S_3 &= \frac{1}{p^2} I(45^\circ, 90^\circ) - S_0 \end{aligned}$$


Drawback, measuring p

43

III Stokes Model

- Stokes measurement : Fourier analysis with a quarter wave plate
- Stokes vector at the output

$$S' = \frac{1}{2} (S_0 + S_1 \cos^2 2\theta + S_2 \sin 2\theta \cos 2\theta - S_3 \sin 2\theta) \begin{pmatrix} 1 \\ 1 \\ 0 \\ 0 \end{pmatrix}$$



- So $S'_0 = I(\theta)$

$$I(\theta) = \frac{1}{2} (S_0 + S_1 \cos^2 2\theta + S_2 \sin 2\theta \cos 2\theta - S_3 \sin 2\theta)$$

44

III Stokes Model

- Stokes measurement : Fourier analysis
- Recognize a Fourier series

$$I(\omega t) = \frac{1}{2} [A - B \sin 2\omega t + C \cos 4\omega t + D \sin 4\omega t] \quad A = S_0 + \frac{S_1}{2} \quad B = S_3 \quad C = \frac{S_1}{2} \quad D = \frac{S_2}{2}$$

- Then :

$$A = \frac{1}{\pi} \int_0^{2\pi} I(\theta) d\theta \quad B = \frac{2}{\pi} \int_0^{2\pi} I(\theta) \sin 2\theta d\theta \quad \text{So} \quad S_0 = A - C$$

$$C = \frac{2}{\pi} \int_0^{2\pi} I(\theta) \cos 4\theta d\theta \quad D = \frac{2}{\pi} \int_0^{2\pi} I(\theta) \sin 4\theta d\theta \quad S_2 = 2D$$

$$S_1 = 2C$$


$$S_3 = B$$

- In practice: plate in a static mount rotated by a stepper motor

45

III Stokes Model

- Stokes measurement principle: configuration with LC



The retarder element is composed with two liquid crystal wave plate



During the measurement of the Q (s1) and V (s3) components the first LC plate is held to zero retardance. It is then tuned to a quarter wave of retardance for the measurement of the U (s2) component

46

III Stokes Model

- Stokes measurement principle: configuration with LC
- First LCVR tuned to no retardance
- Measuring S1
second LCVR tuned to zero and half wave retardance

$$S_1 = \frac{1}{2} \left[\frac{I_T(0) - I_T(\lambda/2)}{I_T(0) + I_T(\lambda/2)} - \frac{I_R(0) - I_R(\lambda/2)}{I_R(0) + I_R(\lambda/2)} \right]$$

- Measuring S3
second LCVR tuned to positive quarter and negative quarter wave


$$S_3 = \frac{1}{2} \left[\frac{I_T(\lambda/4) - I_T(-\lambda/4)}{I_T(\lambda/4) + I_T(-\lambda/4)} - \frac{I_R(\lambda/4) - I_R(-\lambda/4)}{I_R(\lambda/4) + I_R(-\lambda/4)} \right]$$

- Measuring S2 : first LCVR tuned as a quarter wave plate
then same calculation

47

III Stokes Model

- Example of manual Stokes/Mueller setup
- Halogen light source and monochromator



PSA


Object

PSG

48

III Stokes Model


- Example of results ; cf labs
- Measured Stokes vector of a linear wave polarized at 45°



49

III Stokes Model

- Output of the polarimeter: $S_0 = \text{AMW } S_I$
- Rough Mueller images




50

- Need precise calibration procedure

III Stokes Model

• Influence of noise

Noise is amplified



Intensities images SNR=10 dB

Mueller

51

References

- D. L. Goldstein, *Polarized light second Edition (Optical Engineering)* (CRC, 2003).
- Polarization of light, Serge huard, John Wiley, 1997
- Meadowlark optics web site, LCD celles and applications

52